



**IMPORTANT - PLEASE READ THESE INSTRUCTIONS CAREFULLY  
AND KEEP FOR FUTURE REFERENCE**

# Extendable Fireguard 60cm Width Extension

**Instructions for Installation and Use**

## DIMENSIONAL INFORMATION:

This extension is compatible with Clippasafe Extendable Fireguard Model No.1001. It must not be fitted to any other Fireguard. The Fireguard and this extension should be securely fixed in accordance with these instructions such that no part of the Fireguard is closer than 300mm to any exposed burning fuel, heated elements or radiants.

Width of Fireguard with extension fitted: Adjustable from 183cm to 226cm  
Depth: 44cm (50cm including securing hooks and eyes).  
Height: 65cm

## PACK CONTENTS:

Extension Assembly  
Screws x 5  
U Clips x 5  
Instruction Sheet

## TOOLS REQUIRED:

For Assembly:  
Cross Head Screwdriver  
Other tools may be required for wall mounting this Fireguard depending on the surface to which it is to be fitted.

## ASSEMBLY

**1 - 3.** Assemble the left and right Fireguard assemblies in accordance with the Fireguard Instructions.

**4.** Locate the provided U clips at points **A** over the thicker wire frames of the side and top panels of the Left Fireguard assembly and the extension. Insert the provided screws into the U clips and tighten to secure the front and top panels together (Fig. 1).

**5 - 7.** Continue to assemble the extended left assembly to the right assembly following the instructions provided with the fireguard.

## IMPORTANT:

Attach and position in accordance with manufacturer's instructions. The Fireguard and extension must be assembled before use and fitted securely, in accordance with these instructions, to provide adequate protection. Position the Fireguard so that all parts of it are at least 300mm away from any exposed burning fuel, heated elements or radiants.

## MAINTAINING YOUR FIREGUARD AND EXTENSION:

To clean, wipe over with a damp cloth. Do not use harsh abrasives. If your Fireguard becomes chipped, touch up with a non-toxic black enamel paint. Only use genuine replacement parts which are available from the manufacturer.

## SAFETY ADVICE:

**WARNING: No object should be placed on the Fireguard.**

**WARNING: Do not dry washing or air clothes on the Fireguard.**

A Fireguard is designed to protect people from falling into a fire, prevent burns and reduce the risk of injury, particularly to young people and the infirm. It is not intended to reduce the risk of fires caused by flying particles. A Fireguard can become hot to the touch during prolonged use. Children should not be left unattended.

Inspect your Fireguard regularly and do not use if any part is broken or missing.

Only use replacement parts supplied by Clippasafe.

When not in use, this Fireguard should be stored away from children.





Fig. 1

## Clippasafe Ltd.,

Lanthwaite Road, Clifton,  
Nottingham. NG11 8LD. England.

E-mail: [careline@clippasafe.co.uk](mailto:careline@clippasafe.co.uk)

Website: [www.clippasafe.co.uk](http://www.clippasafe.co.uk)

©Clippasafe Ltd 2014 - 1001/1/Sep2014



Complies with BS 8423:2010

**MODEL No.1001/1  
for use with Fireguard  
Model No.1001**